

Tips:

- Do not exert too much pressure because the bit acts like a screw and needs to rotate fully to produce a perfect hole
- Be careful not to drill onto a hard surface as this will damage the bit point when it exits the wood - rather place another piece of wood below as protection.





www.eurekadrillbits.co.za

BLUE FOR METALS

ELLOW FOR WOOD

GREEN **FOR MASONRY**

& CONCRETE

ORANGE

FOR SCREW DRIVING BITS



















